



WASH FOR OUTDOOR FOOTWEAR (SPRAY ON)

The STORM wash for outdoor footwear removes dirt and stubborn stains from shoes and extends their lifespan.

How to use:



Remove coarse dirt from the shoes with the brush, shake the bottle
Spray the cleaner on the damp surface.
Rub in carefully and rinse well
Let dry before use



if necessary impregnate afterwards

Shoes are given a DWR treatment or a hydrophobic tanning during the manufacturing process. This gives the article a water-repellent effect on the surface. Our cleaner offers complete cleaning, but leaves the active DWR untouched and prepares the surface for further treatment if this should be necessary.



restores
breathability



Increases
garment
life span



gentle
to fabrics

ADDITIONAL INFORMATION

- Available in 150 ml
- EAN-Code: 5034886521002