

ULTIMATE TENT CARE KIT



Cleaner for tents, covers and outdoor equipment. Ready to use. Restores the water-repellent effect, removes dirt, tree sap and bird calk, extends the life span of the item.



How to wash:

Shake the bottle and moisten the material



Spray from a distance of 10 to 15 cm



Use a non-scratchy STORM sponge for cleaning. Before repackaging, make sure the material is completely dry

How to proof:

If necessary, clean material with STORM Wash. Shake the bottle well

Spray from a distance of 10 to 5 cm

Moisten a clean cloth with proofer and rub it in. This ensures better performance and reduces ladder formation. Let the tent dry for 12 hours for maximum performance

How to use the sponge:

Paints are not scratched or damaged. Moisten the sponge with water. Use the colored side to detach the dirt and use the other side of the sponge to wipe it clean.

This combination gives you the best possible aftercare. More product information can be found on the individual articles. This care set also includes a sponge and TEAR-AID patches for all-round care.



restores water repellency



lifts dirt, tree sap & bird calk



hygienic finish to gear



Increases garment life span



gentle to fabrics

ADDITIONAL INFORMATION

Contains:

- TENT CARE Spray Wash 225 ml
- Tear Aid Standard Pack (22,5x7,5 cm)
- TENT CARE Spray Proof 225 ml
- EAN-Code: 5034886572073
- Sponge
- Resin stripping card